

VISION PRO LCD Instructions

1. CGA GAME BOARD SELECT

Step 1. Press Menu buton (Main menu will appear)
IMAGE ADJUST will be highlighted press SELECT

Step 2. Press down one time then press SELECT

Step 3. Press UP or DOWN button until your game name appears then press select.

Note: If your EGA & VGA games is not listed in the menu it will require manual adjustment go to IMAGE MENU.

Manual adjustments required

MAIN MENU
IMAGE ADJUST
COLOR SETTINGS
OSD SETTINGS
FUNCTIONS

2. IMAGE MENU (USER SETTINGS)

1. Reset Position - All Positions Reset to Factory Default

2. AUTO ADJUST - Automatically adjust picture.

Use only in VGA or higher resolution.

3. INPUT LEVEL - STEP 1 - High Level

STEP 2 - Medium Level

STEP 3 - Low Level

4. AUTO COLOR - Automatically sets Brightness & contrast and color based on the Input level selected above #3 (above)

If Auto color FAILS then go back to #3 and

change to a different STEP (STEP 1 TO STEP 2 or 3)

Then redo AUTO COLOR until it states "PASS"

5. H-START - Adjusts Horizontal start position of picture
Left side of screen.

6. V-START - Adjusts vertical start position of picture
Top of screen.

7. H-SIZE - Adjusts Horizontal end position of picture
Right side of screen.

8. V-SIZE - Adjusts Vertical end position of picture
Bottom of screen.

9. CLOCK - (DOT Clock) adjusts the total size of picture
from left to right.

10. PHASE - Focus adjustment.


IMAGE MENU	
EXIT	
GAME	
RESET POSTION	
INPUT LEVEL	Step 1
AUTO COLOR	
H-START	892
V-START	31
H-SIZE	640
V-SIZE	480
CLOCK	801
PHASE	97

Available CGA Games


1	Astro Wicked & Wheel & Skill	18	New Fruit & New Cherry
2	Rosen Jack	19	Crazy Bugs & Jungle King
3	Wild Jack	20	Fruit Genie
4	Fruit Pixie	21	Big Boss
5	Super Star Nudge	22	Dino Dino
6	Tic-Tac Fruit	23	Fruit Bonus 2006
7	Bonus Spin	24	Money Machine
8	Fruit Holder	25	Bug Fever
9	Poker Only	26	Fruit Bonus 2005
10	Magic Bomb	27	Fruit Bonus 2nd
11	MGP340Y & CJ8L	28	Queen Bee
12	FOX340	29	Pot of Gold Pace-o-Matic
13	Cadillac Jack	30	New Game or USER mode
14	Triple Jack	31	New Cherry2000
15	Magical Odds	32	Super Fruit Bonus
16	Monkey Land	33	Flaming 7's
17	Special 7's	34	Crusin World or All EGA Games

SUZO HAPP
GAMING, AMUSEMENT AND INDUSTRIAL COMPONENTS


suzohapp.com



VGA Setup Diagram



CGA Setup Diagram



Remote On Screen Display (OSD)



Connector View on Back of LCD